













配件表

編號	部件規格/外觀	數量
1		1
2		2
3		1
4		2
5		1
6		4
7	M8 x 60 	8
8	M8 x 40 	6
9	Ø8 	18
10	M8 	4
11	 M8	1



掛鉤與電視機安裝使用的螺絲：




產品說明

- 適用於40-98吋液晶顯示器，最大承載重量130公斤
- 底座尺寸：1055x470mm · 安裝最大孔距：800x600mm以內
- 支架高度：1700mm(可調高度) · 配置4個2.5吋自鎖腳輪

JR-1347

活動架安裝說明書



WEI-YA
維亞


安裝前了解推車的組合，熟悉配件安裝位置，參照安裝要點步驟，使用對應的配件序號安裝，適合安裝40~98吋顯示器，可以手動調節上下高度

JR-1347 活動架安裝步驟

[步驟 1]

1 x1

6 x4





[步驟 2]

2 x2

8 M8x40 6 pcs

9 Ø8 6 pcs



[步驟 3]

5 x1

7 M8x60 4 pcs


9 Ø8 4 pcs

[步驟 4]

3 x1


7 M8x60 4 pcs

9 Ø8 8 pcs



[步驟 5]

4 x2



[組裝完成尺寸圖]

